

## SECTION XV: EQUALIZING SUB-ASSEMBLIES and ACCESSORIES

## Type 'ROTXR' Pump-Through Bottom Sub-Assembly:

**Rebco** Type 'ROTXR' Pump-Through Bottom Sub-Assemblies are to be used with Lock Mandrels and Equalizing Valves (Valve type) according to the Nominal Size and Profile of the Landing Nipple.

Spring loaded Ball and Seat bottom holds pressure from below only and provide the means of pumping through the Plug. See Section XVIII - Pump-Through Plugs.

<u>NOTE</u>: When ordering Specify Lock Mandrel Size and Type to be used with, and Material to suit Down-hole conditions/requirement.

For Part Numbers and Engineering Data see Section XVI - PLUG CHOKES

DET	PART NAME	QTY	DET
1	CAGE	1	1
2	BALL & SEAT SUB-ASSEMBLY	1 Set	2
3	SPRING RETAINER	1	3
4	SPRING	1	4

