



SECTION I: TOOL STRING

Type 'SO' and 'SD' Spring Jar Assembly: 1 1/2" – 2 1/2"

Rebco Spring Jar is a telescoping up-stroke Jar installed below the Stem.

The impact force can be predetermined at surface by the Operator with the Calibration Unit shown below.

Rebco offers Spring Jars with Threaded or QLS Connections.

Type 'SO' - Threaded Connection

TECHNICAL DATA

NOMINAL SIZE (OD)	ASSEMBLY PART NUMBER	ENGINEERING DATA			
		MAX OD	CONNECTION	FISHING NECK	LENGTH
1 1/2"	10214201500	1.50"	15/16" - 10	1.375"	35.68"
1 3/4"	10214201750	1.75"	1 1/16" - 10	1.750"	37.55"
1 7/8"	10214201870	1.88"			
2 1/8"	10214202120	2.12"			
2 1/2"	10214202500	2.50"	1 9/16" - 10	2.313"	38.65"
	10214202501				38.90"





SECTION I: TOOL STRING


Type '**SD**' - QLS Connection

TECHNICAL DATA					
NOMINAL SIZE (OD)	ASSEMBLY PART NUMBER	ENGINEERING DATA			
		MAX OD	CONNECTION	FISHING NECK	LENGTH
1 1/2"	10214031500	1.50"	'RQLD'	1.375"	42.38"
1 3/4"	10214031750	1.75"		1.750"	43.40"
1 7/8"	10214031870	1.88"			
2 1/8"	10214032120	2.12"			
2 1/2"	10214032500	2.50"		2.313"	44.00"

ACCESSORIES: Shown Tools are necessary to set the Jars for desired Impact.
Tools are priced separately. Order by PART NUMBER shown.

TOOL	SIZE	PART NUMBER
CALIBRATION UNIT	1 1/2" - 2 1/8"	10202161
	2 1/2"	10202162
ADJUSTMENT WRENCH	1 1/2"	1021433
	1 3/4" - 2 1/8"	1021434
	2 1/2"	1021451
RELEASE WRENCH	1 1/2"	1021413
	1 3/4" - 2 1/8"	1021435
	2 1/2"	1021449
		1021450

NOTE: See **Rebco** 'DOM' (Design and Operating Manual) for proper Service and Setting of **Rebco** Type '**SO**' and Type '**SD**' Jars.



Calibration Unit



Adjustment Wrench



Release Wrench

